

**1270 Terminal Control Unit  
Maintenance Manual, Volume I**

**Publication Number 1270.20-01**  
**September 1982**

The information in this publication is subject to periodic revisions and to updates by Publications Bulletins. A bulletin is identified as Publication Number 1270.20-00XX, where "XX" equals "01" for the first bulletin released.

To request copies of this publication or any bulletin, send a Supplies Requisition (form number 7020) using the publication number, to: Memorex Corporation, Marketing Distribution Center, San Tomas at Central Expressway, Santa Clara, California 95052.

A readers' comments form is provided at the back of this publication. If the form has been removed, please send comments to Memorex Corporation, Product Publications, M/S 03-16, San Tomas at Central Expressway, Santa Clara, CA 95052

**Copyright © 1972, 1974, 1979, 1980, 1982 MEMOREX CORPORATION**  
**ALL RIGHTS RESERVED**

## PREFACE

This manual provides Memorex Field Service Representatives with procedural data, maintenance instructions, theory of operation, and testing procedures to be used when servicing the Memorex 1270 Terminal Control Unit. The manual is divided into two volumes. This manual, *Volume I*, provides the procedural data and maintenance instructions for general servicing of the TCU. *Volume II* contains material concerning the theory of 1270 TCU operation and also provides detailed procedures to be used when conducting tests from the test panel of the 1270 TCU.

The contents of *Volume I* of this maintenance manual are divided into six sections. Section 1 describes each of the standard and optional features and groups these features into the functional sections of the 1270 to which they are pertinent. Section 2 provides a procedure for use when installing the TCU and briefly describes each of the options which may be plugged on the 1270 PCBs. Section 3 briefly describes the function of the switches and indicators on both the control panel and each of the roller bar positions of the test panel. Section 4 discusses maintenance aids and the general maintenance requirements for performing scheduled and unscheduled servicing. Section 5 provides instructions for installing and removing replaceable components and Section 6 provides procedures to be used when adjusting components of the power supply assemblies.

In addition to *Volume I* and *Volume II*, *1270 Terminal Control Unit Maintenance Manual*, 1270.20-00, the following publications should be readily available for reference.

- 1270.51-00 *1270 Terminal Control Unit Diagnostic System User's Guide*
- 1270.70-00 *1270 Terminal Control Unit Diagnostic System Reference Card*
- 2870.001 *1270 Terminal Control Unit Illustrated Parts Catalog*
- 2579.001 *Modems Technical Descriptions*
- 2979.001 *Modems General Descriptions*
- The Technical Bulletin Manual*
- Logic Manuals*

# TABLE OF CONTENTS

Section		Page
1	<b>GENERAL INFORMATION</b>	1-1
	1.1 GENERAL DESCRIPTION	1-1
	1.2 MAJOR COMPONENTS AND FEATURES	1-2
	1.2.1 I/O Control Section	1-4
	1.2.2 Terminal Control Section	1-4
	1.2.3 Assemble/Disassemble Section	1-8
	1.2.4 Line Interface Section	1-8
	1.2.4.1 Line Adapter Gates	1-8A
	1.2.4.2 Line Adapters	1-8A
2	<b>INSTALLATION</b>	2-1
	2.1 INSTALLATION REQUIREMENTS	2-1
	2.1.1 Checklist for Planning Phase	2-1
	2.1.2 Installation Procedure	2-1
	2.2 PLUGGING OPTIONS	2-6
	2.2.1 Channel Control Options	2-6
	2.2.2 Master Control Options (MC 4, A23, CC111)	2-10
	2.2.3 Autospeed Feature (Auto Speed Select, B25, CD042)	2-12
	2.2.4 Autocall Feature (Auto Call, B29, CD181)	2-12
	2.2.5 Terminal Control and Speed Select (TC and Speed Select, B26 through B28; CD011, CD021, or CD031)	2-13
	2.2.6 ASCII Terminal Control Options (ASCII Terminal Control, A14 through A17, CD061)	2-14
	2.2.7 IBM-1 and IBM TA-3 Terminal Controls (IBM-1 and/or IBM TA-3, A14 through A17, CD081, or CD221)	2-15
	2.2.8 Code Convert Terminal Controls	2-15
	2.2.9 ASCII Checking Terminal Control Options (ASCII Checking, A14 through A17, CD161)	2-16
	2.2.10 Binary Synchronous Options	2-17
	2.2.11 TIAS Line Adapter	2-19
3	<b>PANEL CONTROLS AND INDICATORS</b>	3-1
	3.1 CONTROL PANEL	3-1
	3.2 OPERATOR CONTROLS AND INDICATORS	3-1
	3.3 TEST PANEL CONTROLS AND INDICATORS	3-3
4	<b>MAINTANANCE AIDS</b>	4-1
	4.1 SAFETY PRECAUTIONS	4-1
	4.1.1 AC Voltages	4-1
	4.1.2 DC Voltages	4-2

## TABLE OF CONTENTS (Continued)

Section		Page
4.2	TEST EQUIPMENT AND TOOLS	4-3
4.2.1	Test Equipment	4-3
4.2.2	Special Tools	4-4
4.3	MAINTENANCE PHILOSOPHY	4-4
4.3.1	Unscheduled Maintenance	4-5
4.3.2	Scheduled Maintenance	4-8
5	<b>REPLACEMENT PROCEDURES</b>	5-1
5.1	GENERAL COMPONENT REPLACEMENT INSTRUCTIONS	5-1
5.2	SERVICE ACCESS PANEL COVERS	5-1
5.2.1	Front and Rear Door Assemblies	5-1
5.2.2	Right and Left Side Covers	5-1
5.3	INDICATOR LAMPS	5-5
5.3.1	Operator Panel Lamps Replacement	5-5
5.3.2	Test Panel Lamps Replacement	5-5
5.4	DC POWER SUPPLY ASSEMBLY	5-7
5.4.1	Regulator PCB Replacement	5-10
5.4.2	Control Circuit PCB Replacement	5-10
5.4.3	DC Power Supply Assembly Replacement	5-10
5.5	LINE FILTER ASSEMBLY REPLACEMENT	5-11
5.6	BLOWER ASSEMBLY REPLACEMENT	5-12
5.7	REPLACING FUSES AND POWER COMPONENTS	5-14
5.7.1	Sequencer Fuses	5-14
5.7.2	DC Power supply Fuses	5-14
5.7.3	Power Sequence Unit Assembly Replacement	5-14
5.8	CONNECTOR PANEL ASSEMBLY	5-15
5.9	PRINTED CIRCUIT BOARDS	5-18
5.9.1	Logic Gate Arrangement	5-18
5.9.2	PCB Removal Procedure	5-20
5.9.3	PCB Installation Procedure	5-20
6	<b>CHECKS AND ADJUSTMENTS</b>	6-1
6.1	GENERAL INSTRUCTIONS	6-1
6.2	LAMP TEST	6-1
6.3	INPUT POWER ADJUSTMENT (208/230 VAC)	6-1
6.4	DC POWER SUPPLY	6-2
6.4.1	Circuit Description	6-2
6.4.2	Voltage Calibration	6-3
6.5	MODEM CALIBRATION	6-6

## LIST OF ILLUSTRATIONS

Figure		Page
1-1	Examples of Compatible Devices .....	1-2
1-2	Major Components and Basic Data Flow of the 1270 TCU.....	1-3
3-1	Operator Controls and Indicators .....	3-1
3-2	Test Panel Switches.....	3-3
3-3	Roller A Indicators .....	3-7
3-4	Roller B Indicators .....	3-10
3-5	Roller C Indicators .....	3-11
3-6	Roller D Indicators .....	3-12
3-7	Roller E Indicators .....	3-13
3-8	Roller F Indicators.....	3-14
3-9	Roller G Indicators .....	3-16
3-10	Roller H Indicators .....	3-18
4-1	Conditions for Online and Offline Servicing .....	4-6
5-1	1270 Major Assembly Locations (Front View) .....	5-2
5-2	1270 Major Assembly Locations (Interior Front View) .....	5-3
5-3	1270 Major Assembly Locations (Read View).....	5-4
5-4	Indicator Numbers for Reference to Indicator Selector PCBs .....	5-6
5-5a	DC Power Supply Assembly (ELC 300).....	5-8
5-5b	DC Power Supply Assembly (Below ELC 300) .....	5-9
5-6	Line Filter Assembly Details .....	5-11
5-7	Blower Assembly Details .....	5-13
5-8	Power Sequence Unit Assembly.....	5-15
5-9	Power Circuit Connections.....	5-16
5-10	Connector Panel Details .....	5-17
5-11	Gate Connections for Communication Lines.....	5-19
5-12	A Gate Card Position Reference Chart .....	5-21
5-13	B Gate Card Position Reference Chart .....	5-22
6-1	Input Power Adjustment (208/230 VAC).....	6-2
6-2	TCU Power Supply, Block Diagram .....	6-4
6-3	Power Supply Adjustment Points.....	6-5


TABLE OF CONTENTS (Continued)  
**LIST OF TABLES**

Table		Page
1-1	EXAMPLES OF WIDEBAND LINE ADAPTER FEATURE .....	1-9
2-1	SPECIFICATIONS .....	2-2
3-1	FUNCTIONS OF OPERATOR CONTROLS AND INDICATORS .....	3-2
3-2	TEST PANEL SWITCHES .....	3-4
3-3	ROLLER A INDICATORS .....	3-7
3-4	ROLLER B INDICATORS .....	3-10
3-5	ROLLER C INDICATORS .....	3-11
3-6	ROLLER D INDICATORS .....	3-13
3-7	ROLLER E INDICATORS .....	3-13
3-8	ROLLER F INDICATORS .....	3-15
3-9	ROLLER G INDICATORS .....	3-16
3-10	ROLLER H INDICATORS .....	3-19
4-1	PREVENTIVE MAINTENANCE SCHEDULE .....	4-8
<p style="text-align: center;">UNBLOCKING AND TUNING</p> <p>4.1      INITIAL BY OPERATOR</p> <p>4.2      LAMP TEST</p> <p>4.3      INPUT POWER ADJUSTMENT (MODERN)</p> <p>4.4      DC POWER SUPPLY</p> <p>    4.4.1      Check Operation</p> <p>    4.4.2      Voltage Calibration</p> <p>4.5      MODERN CALIBRATION</p>		

# LIST OF TABLES

1-1

1-1 CHAMFER  
2-1 SPECIFICATIONS  
3-1 FUNCTION  
3-2 TEST PANEL  
3-3 ROLLER A  
3-4 ROLLER B  
3-5 ROLLER C  
3-6 ROLLER D  
3-7 ROLLER E  
3-8 ROLLER F  
3-9 ROLLER G  
3-10 ROLLER H  
4-1 PREVENT



1-2  
1-3  
1-4  
1-5  
1-6  
1-7  
1-8  
1-9  
1-10  
1-11  
1-12  
1-13  
1-14  
1-15  
1-16  
1-17  
1-18  
1-19  
1-20  
1-21  
1-22  
1-23  
1-24  
1-25  
1-26  
1-27  
1-28  
1-29  
1-30  
1-31  
1-32  
1-33  
1-34  
1-35  
1-36  
1-37  
1-38  
1-39  
1-40  
1-41  
1-42  
1-43  
1-44  
1-45  
1-46  
1-47  
1-48  
1-49  
1-50  
1-51  
1-52  
1-53  
1-54  
1-55  
1-56  
1-57  
1-58  
1-59  
1-60  
1-61  
1-62  
1-63  
1-64  
1-65  
1-66  
1-67  
1-68  
1-69  
1-70  
1-71  
1-72  
1-73  
1-74  
1-75  
1-76  
1-77  
1-78  
1-79  
1-80  
1-81  
1-82  
1-83  
1-84  
1-85  
1-86  
1-87  
1-88  
1-89  
1-90  
1-91  
1-92  
1-93  
1-94  
1-95  
1-96  
1-97  
1-98  
1-99  
1-100

Memorex 1270 Terminal Control Unit



# SECTION 1.

## GENERAL INFORMATION

### 1.1 GENERAL DESCRIPTION

The Memorex 1270 Terminal Control Unit is designed to provide the IBM System/360 or System/370 user with a versatile interface to a wide range of local and remote communication devices. In providing this versatility, the 1270 accommodates 1 to 96 communication lines and is capable of operation in half- or full-duplex mode over two- or four-wire facilities for asynchronous (start/stop) and synchronous transmissions. Asynchronous transmission facilities may be voice grade and may be switched, leased, or privately owned. Synchronous transmission facilities are supported via voice-grade and wideband line control.

For low-speed transmissions, the basic 1270 supports communication terminals in asynchronous mode at line speeds of 110, 134.5, 150, 300, 600, and 1200 bits per second (bps). Synchronous mode is used for high-speed devices which follow established IBM Binary Synchronous Communication (BSC) conventions and is supported at line speeds up to 9,600 bps with a synchronous adapter and up to 50,000 bps with a wideband adapter. Figure 1-1 illustrates the types of devices that can be attached to the 1270.

The 1270 attaches to the multiplexer channel of the IBM System/360 or System/370. When communicating with the channel, the 1270 operates in multiple-byte multiplex mode to request and transfer data to or from the CPU. Data is transferred in bursts of up to four bytes during any one I/O channel servicing cycle. In communicating with a remote terminal, the 1270 transmits and receives serially by bit. It provides internal character buffering of up to eight bytes for both asynchronous and synchronous transmissions. The 1270 does not impose restrictions on message length and may be equipped to recognize and translate transmission codes which do not exceed an eight-level, eleven-unit structure (eight data bits and three start/stop bits). These transmission codes include ASCII, Correspondence, PTTC, and BCD in asynchronous mode and ASCII and EBCDIC in synchronous mode. Synchronous transparency is also supported.

All character and bit control, character decoding, data handling, and matching to common-carrier equipment is accomplished by the functional sections within the 1270. Specifically, the 1270 performs the following functions, when applicable, during a transmit or receive operation:

- Inserts and deletes certain control characters that are required by the remote terminals but which are not part of the data required by the CPU.
- Generates timeout intervals to ensure that no unreasonable delays occur.
- Handles the polling and selection of remote terminals under control of the CPU.
- Provides for the recognition of different transmission codes and speeds.
- Signals an interrupt to the CPU when the data transmission is ended.



























